



CAMERA/RADIO LOOP SEWING INSTRUCTIONS

1. Identify the appropriate placement for your camera loop according to your height.
2. Align attachment with center front placket edge, sew one side of loop to placket (see figure 1).
3. Align opposite edge with placket edge and sew (see figure 2)
4. Insert your radio or camera (see figure 3)