5.11 ILV6 ATTACHMENT MANUAL



QUICK RELEASE SETUP 01: + Release buckles on backpack



QUICK RELEASE SETUP 02: + Insert buckle through lower webbing loop on back of LV6



QUICK RELEASE SETUP 03: + Insert buckle through upper webbing loop on LV6



QUICK RELEASE SETUP 04: + Connect S/R buckle



QUICK RELEASE SETUP 05: + Repeat on other side + Pull straps to tighten down

5.11 TACTICAL® 1360 REYNOLDS, SUITE 101 IRVINE, CA 92614, USA

866.451.1726 | WWW.511TACTICAL.COM

5.11

01

5.11 ILV6 ATTACHMENT MANUAL



SEMI-PERMANENT SETUP 01: + Squeeze gate keeper on LV6 to release the keeper



SEMI-PERMANENT SETUP 02:

- + Remove the gate keeper from the webbing loop and the strap
- + Store the strap



SEMI-PERMANENT SETUP 03:

+ Insert the bottom of gate keeper in the top webbing loops of the LV6 with the opening of the keeper facing the center of the bag



SEMI-PERMANENT SETUP 04: + Release the buckles on the lower backpack straps



SEMI-PERMANENT SETUP 05:

- + Insert the top of the gate keeper in the same webbing loop as the S/R buckle on the backpack
- + Make sure the keeper is on top of the S/R buckle
- + Close the gate keeper

5.11 (±) ^{5,11} TACTICAL* 1560 REF VAIOLS, SUITE TOT IRVINE, CA 92614, USA 866.451.1726 | WWW.511TACTICAL.COM



SEMI-PERMANENT SETUP 06: + Repeat on other side

02

5.11 ILV6 ATTACHMENT MANUAL



SEMI-PERMANENT SETUP 01: + Insert the S/R buckle through the lower webbing loop on the LV6



SEMI-PERMANENT SETUP 02: + Connect the S/R buckle



SEMI-PERMANENT SETUP 03: + Pull straps to tighten down

03

